

# CHC<sup>®</sup> M6 GNSS Receiver

Revision 1.0  
October 2017



**Copyright**

Copyright 2016-2017 CHC | Shanghai Huace Navigation Technology Ltd. All rights reserved. The CHC are trademark of Shanghai Huace Navigation Technology Limited. All other trademarks are the property of their respective owners.

**Trademarks**

All product and brand names mentioned in this publication are trademarks of their respective holders.

**Safety Warnings**

The Global Positioning System (GPS) is operated by the U.S. Government, which is solely responsible for the accuracy and maintenance of the GPS network. Accuracy can also be affected by poor satellite geometry and obstructions, like buildings and heavy canopy.

*M6 GNSS Receiver User Guide  
Revision 1.0 October 2017*

# CONTENTS

1. Introduction .....	4
1.1. Safety information .....	4
1.1.1. Warnings and cautions .....	4
1.1.2. Regulations and safety .....	4
1.1.3. Use and Care .....	5
1.2. Technical support .....	5
1.3. Disclaimer .....	5
1.4. Your comments .....	5
2. Getting started with M6 .....	6
2.1. About the receiver .....	6
2.2. Parts of the receiver .....	6
2.2.1. Front panel .....	6
2.2.2. Lower housing .....	8
2.2.3. Receiver ports .....	9
2.3. Batteries and power .....	9
2.3.1. Internal battery .....	9
2.3.1.1. Charging the battery .....	9
2.3.1.2. Battery safe .....	10
2.3.2. External power supply .....	11
2.4. Inserting battery and SIM card .....	11
2.5. Product basic supply accessories .....	12
2.5.1. Base kit basic supply .....	12
2.5.2. Rover kit basic supply .....	14
2.6. Connecting to an office computer .....	15
2.7. Connecting to a controller .....	15
2.7.1. Connecting via Wi-Fi with LandStar 7 software .....	15
2.7.2. Connecting via Bluetooth with LandStar 7 software .....	17
2.8. Downloading logged data .....	19
3. Base station setup and operation .....	21
3.1. Base station setup guidelines .....	21
3.2. Outputting corrections using external radio and network .....	22
4. Rover station setup and operation .....	25
4.1. Rover station setup guidelines .....	25
4.2. Rover station setup .....	26
5. Configuring through a web browser .....	27
5.1. Status menu .....	28
5.1.1. Position submenu .....	28
5.1.2. Activity submenu .....	29
5.1.3. Google Map submenu .....	30
5.2. Satellites menu .....	30
5.2.1. Tracking Table submenu .....	30
5.2.2. Tracking Info. Table submenu .....	31

5.2.3. Tracking SkyPlot submenu .....	31
5.2.4. Satellite Activation submenu .....	31
5.3. Receiver Configuration menu .....	32
5.3.1. Description.....	32
5.3.2. Antenna Configuration submenu.....	32
5.3.3. Reference Station Settings submenu .....	33
5.3.4. Receiver Reset submenu.....	35
5.3.5. Languages submenu .....	35
5.3.6. User Management submenu .....	35
5.3.7. USB Function Switch submenu .....	35
5.3.8. HCPPP Settings submenu.....	35
5.3.9. 1PPS submenu .....	36
5.4. Data Recording menu .....	36
5.4.1. Log Settings submenu.....	36
5.4.2. FTP Push Settings submenu .....	38
5.4.3. FTP Push log submenu .....	39
5.4.4. Data Download submenu .....	39
5.5. IO Settings menu .....	40
5.5.1. IO Settings submenu.....	40
5.6. Network Setting menu.....	44
5.6.1. Description submenu.....	44
5.6.2. Mobile network setting submenu .....	44
5.6.3. Email alarm submenu .....	45
5.6.4. HTTP submenu.....	45
5.6.5. HTTPS submenu .....	45
5.6.6. FTP service submenu .....	46
5.7. Module setting menu .....	46
5.7.1. Description submenu.....	46
5.7.2. Wi-Fi submenu .....	47
5.7.3. Bluetooth settings submenu.....	47
5.7.4. Buzzer setting submenu.....	47
5.8. Firmware menu .....	48
5.8.1. Firmware Info submenu .....	48
5.8.2. Hardware Version .....	48
5.8.3. Config File .....	49
5.8.4. System Log Download submenu .....	49
5.8.5. User Log .....	49
5.8.6. Firmware Update submenu .....	49
5.8.7. GNSS Board Upgrade .....	50
5.8.8. Radio Upgrade .....	50
5.8.9. Upgrade Online .....	50
5.8.10. GNSS Registration submenu .....	50
5.9. Cloud Service Setting menu.....	51
5.9.1. Cloud Service Setting submenu .....	51

A. Communication ports definition .....	52
A.1. CHC M6 receiver IO port (7-pin Lemo port) definition.....	52

# 1. INTRODUCTION

The M6 GNSS Receiver User Guide describes how to set up and use the CHC®M6 GNSS receiver.

In this manual, “the receiver” refers to the M6 GNSS receiver unless otherwise stated.

Even if you have used other Global Navigation Satellite Systems (GNSS) products before, CHC recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to [www.chcnv.com](http://www.chcnv.com) for an interactive look at CHC and GNSS.

## 1.1. SAFETY INFORMATION

### 1.1.1. WARNINGS AND CAUTIONS

An absence of specific alerts does not mean that there are no safety risks involved.

A Warning or Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.



**WARNING** - A Warning alerts you to a potential misused or wrong setting of the equipment.



**CAUTION** - A Caution alerts you to a possible risk of serious injury to your person and/or damage to the equipment.

### 1.1.2. REGULATIONS AND SAFETY

The receivers contain a built-in wireless modem for signal communication through Bluetooth® wireless technology or through external communication datalink. Regulations regarding the use of the wireless modem vary greatly from country to country. In some countries, the unit can be used without obtaining an end-user license. However, in some countries, the administrative permissions are required. For license information, consult your local dealer. Bluetooth® operates in license-free bands.

Before operating a M6 GNSS receiver, determine if authorization or a license to operate the unit is required in your country. It is the responsibility of the end-user to obtain an operator's permit or license for the receiver for the location or country of use.

### 1.1.3. USE AND CARE

This receiver is designed to withstand the rough environment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



CAUTION - Operating or storing the receiver outside the specified temperature range will cause irreversible damage.

## 1.2. TECHNICAL SUPPORT

If you have a problem and cannot find the information you need in this manual or CHC website ([www.chcnav.com](http://www.chcnav.com)), contact your local CHC dealer from which you purchased the receiver(s).

If you need to contact CHC technical support, please contact us by email ([support@chcnav.com](mailto:support@chcnav.com)) or Skype (chc\_support).

## 1.3. DISCLAIMER

Before using the receiver, please make sure that you have read and understood this User Guide, as well as the safety information. CHC holds no responsibility for the wrong operation by users and for the losses incurred by the wrong understanding about this User Guide. However, CHC reserves the rights to update and optimize the contents in this guide regularly. Please contact your local CHC dealer for new information.

## 1.4. YOUR COMMENTS

Your feedback about this user guide will help us to improve it in future revision. Please email your comments to [support@chcnav.com](mailto:support@chcnav.com).

## 2. GETTING STARTED WITH M6

### 2.1. ABOUT THE RECEIVER

The M6 GNSS receiver incorporates a GNSS engine, 3.75G cellular modem, Bluetooth, Wi-Fi, and single-battery in a ruggedized and miniature unit that is easy for you to set up an all-in-one RTK rover or mobile base station. Bluetooth and Wi-Fi technology provide cable-free communication between the receiver and controller.

The receiver can be used as the part of a RTK GNSS system with CHC LansStar7 software. And you can download the GNSS data that recorded in the internal memory of receiver to a computer.

To configure the receiver for performing a wide variety of functions, you can use the web interface by connecting the receiver with PC or smartphone through Wi-Fi.

### 2.2. PARTS OF THE RECEIVER

The operating controls are all located on the front panel. Battery compartment and SIM card slot are on the bottom. Serial ports and connectors are also located on the bottom of the unit.


#### 2.2.1. FRONT PANEL

The following figure shows a front view of the receiver.



The front panel contains five indicator LEDs, and two buttons.





Name	Description
Power LED(Red)	<p>The indicator to show whether M6 GNSS is on or off.</p> <ul style="list-style-type: none"> <li>When battery is less than 20% the Power LED will flash continuously which reminds you to change the battery.</li> </ul>
Satellite LED (Green)	<p>Shows the number of satellites that the receiver has tracked.</p> <ul style="list-style-type: none"> <li>When the receiver is searching satellites, the green LED flashes once every 5 seconds.</li> <li>When the receiver has tracked N satellites, the green LED will flash N times every 5 seconds.</li> </ul>
Correction LED (Green)	<p>Indicates whether the receiver is transmitting/receiving differential data.</p> <p>The green LED flashes once per second when</p> <ul style="list-style-type: none"> <li>As a Base station: successfully transmitting differential data.</li> <li>As a Rover station: successfully receiving differential data from Base station.</li> </ul>
Wi-Fi LED (Orange)	<p>Indicates the status of Wi-Fi.</p> <ul style="list-style-type: none"> <li>When the Wi-Fi LED is orange continuously, Wi-Fi is opening.</li> </ul>
Record LED(Yellow)	<p>The record LED only flashes under two situations</p> <p>A. In static mode.</p> <p>The interval of flashing shows the sample interval of collecting data.</p> <p>B. RTK mode</p> <p>When the receiver is connecting to Controller and receiving commands or just communicating with</p>

---

Controller.

Switch button                      Press Switch button to open or close static mode.

Power button                      Turn on or turn off the receiver.

- Press and hold this button for 3 seconds to turn on or turn off the receiver.

---



### 2.2.2. LOWER HOUSING

The lower housing contains one SIM card slot, one battery compartment, one TNC radio antenna connector, two communication and power ports, one 5/8-11 threaded insert, and two nameplates.



### 2.2.3. RECEIVER PORTS



Port	Name	Description
	IO port	<ul style="list-style-type: none"> <li>This port is a 7-pin Lemo connector that supports RS-232 communications and external power input.</li> <li>Users can use GPS to PC Data Cable supplied with the system to realize RS-232 communications between the receiver and computer or controller.</li> </ul>
	USB port	<ul style="list-style-type: none"> <li>This port is a mini-USB connector that supports USB communications.</li> <li>Users can use USB Cable supplied with the system to download the logged data to a computer.</li> </ul>

## 2.3. BATTERIES AND POWER

### 2.3.1. INTERNAL BATTERY

The receiver has one rechargeable Lithium-ion battery, which can support for charging.

#### 2.3.1.1. Charging the battery

To charge the battery, first remove the battery from the receiver, and then place it in the battery charger, which is connected to AC power.



WARNING - Charge and use the Lithium-ion battery only in strict accordance with the instructions. Charging or using the battery in unauthorized equipment can cause an explosion or fire, and can result in personal injury and/or equipment damage.

To prevent injury or damage:

- Do not charge or use the battery if it appears to be damaged or leaking.
- Charge the Lithium-ion battery only in a CHC product that is specified to charge it. Be sure to follow all instructions that are provided with the battery charger.
- Discontinue charging a battery that gives off extreme heat or a burning odor.
- Use the battery only in CHC equipment that is specified to use it.
- Use the battery only for its intended use and according to the instructions in the product documentation.

#### 2.3.1.2. Battery safe



WARNING - Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire, and can result in personal injury and/or property damage.

To prevent injury or damage:

- Do not use or charge the battery if it appears to be damaged. Signs of damage include, but are not limited to, discoloration, warping, and leaking battery fluid.
- Do not expose the battery to fire, high temperature, or direct sunlight.
- Do not immerse the battery in water.
- Do not use or store the battery inside a vehicle under hot weather condition.
- Do not drop or puncture the battery.
- Do not open the battery or short-circuit its contacts.



WARNING - Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. Battery fluid is corrosive, and contact with it can result in personal injury and/or property damage.

To prevent injury or damage:


- If the battery leaks, avoid with the battery fluid.
- If battery fluid gets into your eyes, immediately rinses your eyes with clean water and seek medical attention. Please do not rub your eyes!
- If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.

### 2.3.2. EXTERNAL POWER SUPPLY

Two methods are available for providing the external power to the receiver by the GPS to PC Data Cable+ Power Adapter, or GPS to PC Data Cable + external power cable (option purchase)+ vehicle battery.

In the office:

The Power Adapter is connecting with AC power of 100-240V, the output port of the Power Adapter connects with the Power Port of the GPS to PC Data Cable.



In the field:

The external power cable is connecting with a vehicle battery, the output port of the external power cable connects with the Power Port of the GPS to PC Data Cable.




**WARNING** - Use caution when connecting external power cable's clip leads to a vehicle battery. Do not allow any metal object to connect (short) the battery's positive (+) terminal to either the negative (-) terminal or the metal part of the vehicle battery. This could result in high current, arcing, and high temperatures, exposing the user to possible injury.

### 2.4. INSERTING BATTERY AND SIM CARD




1. Press the spring-loaded button on the battery cover to open the cover.
2. Insert the SIM card into the SIM card slot.
3. To remove the SIM card, take out directly.
4. Insert the battery into the battery compartment.

5. To remove the battery, take out directly.



## 2.5. PRODUCT BASIC SUPPLY ACCESSORIES

### 2.5.1. BASE KIT BASIC SUPPLY

Item	Picture
M6 GNSS Receiver	
USB Data Cable	
GPS to PC Data Cable	

USB2.0 convert to RS232 serial port



Lithium Battery



External power cable



Battery Charger



H.I. Tape



Extension pole



Tribrach with optical plummet



Auxiliary H.I. Tool



Tribrach adaptor



Transport Hard Case



2.5.2. ROVER KIT BASIC SUPPLY

Item	Picture
M6 GNSS Receiver	
USB Data Cable	
GPS to PC Data Cable	
USB2.0 convert to RS232 serial port	
Battery Charger	
External power cable	
Lithium Battery	
2M Range Pole w/bag	
Auxiliary H.I. Tool	



Transport Hard Case




---

## 2.6. CONNECTING TO AN OFFICE COMPUTER

The receiver can be connected to an office computer for serial data transfer or settings via a GPS to PC Data Cable. Before you connect to the office computer, ensure that the receiver is powered on by internal battery or external power.


The following figure shows how to connect to the computer for serial data transfer or settings:




## 2.7. CONNECTING TO A CONTROLLER

### 2.7.1. CONNECTING VIA WI-FI WITH LANDSTAR 7 SOFTWARE


1. Turn on the controller → run LandStar 7 → go to **Config** main menu → tap **Connect**.
2. In the *Connect* screen, select **CHC** for the *Manufacture* field, **i80** for *Device Type* field, **Wi-Fi** for *Connection Type* field,



3. Tap the Wireless Lan icon on the right side to select the hot-spot → Switch on the Wi-Fi module by the top switch → tap refresh button to search the hot spot around → select the target device in the list.




4. Tap **Connect** to link to the hot spot. If the first-time connection to this hot spot, user may type in the password.




*Tip – The Wi-Fi key of the receiver is 12345678 by default.*

5. Tap the **Connect** button to build the connection.




### 2.7.2. CONNECTING VIA BLUETOOTH WITH LANDSTAR 7 SOFTWARE


1. Turn on the controller → run LandStar 7 → go to **Config** main menu → tap **Connect**.
2. In the *Connect* screen, select **CHC** for the *Manufacture* field, **M6** for *Device Type* field, **Bluetooth** for *Connection Type* field.




3. Tap the **Bluetooth Manager** and turn on the **Bluetooth** function to search bluetooth device around → select the target device in the list.



4. Tap **Pair** to connect the bluetooth device → selected the target device in the bluetooth manager list.



5. Tap the **Connect** button to build the connection.



## 2.8. DOWNLOADING LOGGED DATA


Data logging involves the collection of GNSS measurement data over a period at a static point or points, and subsequent postprocessing of the information to accurately compute baseline information. Data logging using receivers requires access to suitable GNSS postprocessing software such as the CHC Geomatics Office (CGO) Software.

The procedures of downloading logged data in the receiver are as follows:

1. Switch on the receiver and connect it with a computer by USB Cable.

After the successful connection, a removable disk named as the Serial Number (SN) of the receiver will appear on the computer.

2. Double click the removable disk and you will see the folder named as “repo”. Double click this folder, you will see 9 folders. The “push\_log” folder is used to save the log files, and the other 8 folders represent different logging session and are used for store static data.
3. Double click the folder that you have configured to store the static data, you will see the folder(s) created by the M6 system automatically and named by the date which is decide by GPS time when you start to log data.
4. Select the destination folder and double click it, and then two folders named as different data format (HCN and RINEX) will be displayed.
5. Select the data format that you have configured to save the static data, you will find the static raw data.



*Tip – For HCN files, the name of the file is represented as XXXXXXDDDNN, where XXXXXX is the SN of the receiver, DDD is day of year, and NN is the recording session.*



**WARNING** – The static data will be saved in the first logging session, the “record\_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

### 3. BASE STATION SETUP AND OPERATION

Real-Time Kinematic (RTK) operation provides centimeter-level precision by eliminating errors that are present in the GNSS system. For all RTK operations, you require both a rover receiver and a source of corrections from a base station or network of base stations.

A base station consists of a receiver that is placed at a known point. The receiver tracks the same satellites that are being tracked by the rover receiver simultaneously. Errors in the GNSS system are monitored at the base station, and a series of position corrections are computed. The messages are sent through a radio link to the rover receiver, where they are used to correct the real-time positions of the rover.

This chapter provides the information to help you identify good setup locations, outlines basic precautions that you need to take to protect the equipment, and describes the conventional process to set up the base station and the configuring procedure that required for transmitting correction data.

#### 3.1. BASE STATION SETUP GUIDELINES

For good performance, the following base station setup guidelines are recommended:

- Place the GNSS receiver in a location on the worksite where equal range in all directions provides full coverage of the site.
- Place the GNSS antenna in a location that has a clear line of sight to the sky in all directions. Do not place the antenna near vertical obstructions such as buildings, deep cuttings, site vehicles, towers, or tree canopy.
- The GNSS antenna must have a clear line of sight to the sky always during operation.
- Make sure that the GNSS receiver does not lose power. To operate continuously for more than a few hours without loss of power at the base station, provide external power. When you use an external power supply, the integrated battery provides a backup power supply, enabling you to maintain continuous operation through a mains power failure.
- Do not locate a GNSS receiver, GNSS antenna within 400 meters (about 1,300 feet) of transmitters, such as a power radar or cellular communications tower.
- Do not set up the base station close to the sources of electromagnetic interference, include alternators and generators, electric motors, equipment with DC-to-AC converters, etc.
- Do not operate the receiver outside the specified operating

temperature range -40°C to +60°C (-40°F to +140°F).

- Take reasonable care to keep the GNSS receiver equipment dry, which could prolong their life and reduce the effects of corrosion on ports and connectors.

## 3.2. OUTPUTTING CORRECTIONS USING EXTERNAL RADIO AND NETWORK

### For External Radio Mode

#### For base receiver part:

1. Screw the M6 receiver onto extension pole.
2. Screw the extension pole with auxiliary H.I. tool onto tribrach adaptor.
3. Mount the tribrach onto the tripod.
4. Insert the tribrach adaptor into the tribrach.
5. Level and plumb the receiver over the known (control) point.
6. Measure the height of the base station GNSS antenna by measuring the slant height from the known (control) point to the auxiliary H.I. tool.

*Note – After entered the vertical height from the known (control) point to the bottom of receiver that you calculated by adding the height of the extension pole to the height from the known (control) point to the end of auxiliary H.I. tool, LandStar 7 will calculate the height to the Antenna Phase Center (APC) automatically.*

7. If required, connect the receiver to an external 12 V power supply.

#### For external radio part (take the CHC DL6 Datalink for example):

8. Connect the Datalink Antenna to the 3-meter Cable for Datalink Antenna.
9. Connect 3-meter Cable for Datalink Antenna to Datalink Antenna Mounting Pole.
10. Screw the Datalink Antenna Mounting Pole onto the tribrach adapter.
11. Mount the tribrach onto the tripod.
12. Insert the tribrach adaptor into the tribrach.
13. Set up the Datalink Antenna nearby the base receiver.
14. Fix the DL6 Datalink onto the tripod.
15. Place the car battery at an appropriate location.

#### For connection between the receiver part and external radio part:



16. Connect Datalink Antenna to the Datalink Antenna Slot of DL6 Datalink via 3-meter Cable for Datalink Antenna.
17. Connect the base receiver with DL6 Datalink via GPS to Datalink Cable.
18. Connect the car battery with DL6 Datalink via Datalink External Power Cable.



CAUTION – The Datalink Antenna must be connected to the Datalink before the Datalink is powered on; otherwise, the Datalink can be damaged.



## For Network Mode

1. Insert the SIM card into M6 GNSS receiver.
2. Screw the M6 receiver onto extension pole.
3. Screw the extension pole with auxiliary H.I. tool onto tribrach adaptor.
4. Mount the tribrach onto the tripod.
5. Insert the tribrach adaptor into the tribrach.
6. Level and plumb the receiver over the known (control) point.
7. Measure the height of the base station GNSS antenna by measuring the slant height from the known (control) point to the auxiliary H.I. tool.



## 4. ROVER STATION SETUP AND OPERATION

Real-Time Kinematic (RTK) operation provides centimeter-level precision by eliminating errors that are present in the GNSS system. For all RTK operations, you require both a rover receiver and a source of corrections from network of base stations.

The second part of the RTK GNSS system is the rover receiver. The rover receiver is moved between the points that require measurement or stakeout. The rover receiver is connected to a source of RTK corrections such as a CORS (Continuous Operational Reference System) or the CHC APIS service. The connection is provided by:

- an integrated cellular modem
- a cellular modem in the controller

This chapter provides the information to help you identify good setup locations, describes the conventional process to set up the rover station and the configuring procedure that required for receiving correction data.

### 4.1. ROVER STATION SETUP GUIDELINES

For good rover operation, observe the following setup guidelines:

- Place the GNSS antenna in a location that has a clear line of sight to the sky in all directions. Do not place the antenna near vertical obstructions such as buildings, deep cuttings, site vehicles, towers, or tree canopy. GNSS rovers and the base station receive the same satellite signals from the same satellites. The system needs five common satellites to provide RTK positioning.



**WARNING** – Take care not to touch overhead power lines with the CHC M6 GNSS receiver or the range pole when moving the equipment into position. Touching overhead power lines may cause electrocution, leading to serious injury.

- GNSS satellites are constantly moving. Because you cannot measure at a specific location now does not mean that you will not be able to measure there later, when satellite coverage at the location improves.
- To get a fixed position solution with centimeter precision, initialize the RTK rover receiver. For initialization to take place, the receiver must track at least five satellites that the base station is also tracking. In a dual-satellite constellation operation, for example, GPS and GLONASS, the receiver must track at least six satellites.
- To continue to survey at centimeter precision, the rover must

continuously track at least four satellites that the base station is also tracking.

- Loss of the satellite signals will result in a loss of centimeter position precision.

## 4.2. ROVER STATION SETUP

1. Screw the receiver on top of the range pole.
2. Fix the controller bracket on the range pole.
3. Fit the controller in the controller bracket.
4. Level and plumb the receiver over the target measuring point.




## 5. CONFIGURING THROUGH A WEB BROWSER

Supported browsers:


- Google Chrome
- Microsoft Internet Explorer® version 10, or higher

To connect to the receiver through a web browser:

1. Turn on the Wi-Fi of the receiver.
2. Search the wireless network named as GNSS-XXXXXXX (the SN of your receiver) on your computer, and then establish the connection.
3. After the successful connection between your computer and the receiver, enter the IP address of the receiver into the address bar of the web browser on your computer:



4. The web browser prompts you to enter a login account and password:


A screenshot of a web browser displaying a login page for a GNSS receiver. The page has a blue header with the text "GNSS" in white. Below the header, there are two input fields: "Login Account:" and "Password:". Below the password field, there is a checkbox labeled "remember me" and a "Login" button. At the bottom of the page, there is a small note in orange text that says "Please Use Chrome, IE10+ or Safari to Open".

The default login account for the receiver is:

- Login Account: admin
- Password: password

*Note – Tick **remember me** option, and then the browser will remember the Login Account and Password you entered for the next time you enter this login screen.*

5. Once you are logged in, the web page appears as follows:




This web page shows the configuration menus on the left of the browser window, and the setting on the right. Each configuration menu contains the related submenus to configure the receiver and monitor receiver performance.

This chapter describes each configuration menu.


To view the web page in another language, select the corresponding language name from the dropdown list on the upper right corner of the web page.

Currently, three languages are available:



## 5.1. STATUS MENU

This menu provides a quick link to review the receiver's position information, satellites tracked, runtime, current data log status, current outputs, available memory, and more.



### 5.1.1. POSITION SUBMENU

This page shows the relevant position information about the receiver's position solution which including the position, DOP values, satellites used

and tracked, and the receiver clock information.

Position	
<b>Position</b>	<b>DOP</b>
Latitude: 31°9'58.72613874"(North)	PDOP: 1.220000
Longitude: 121°17'18.99714793"(East)	HDOP: 0.682000
Height: 28.304	VDOP: 1.011571
Type: 3D	TDOP: 0.713000
<b>Satellite Used: 21Total</b>	<b>Satellites Tracked: 21Total</b>
GPS(6): 1,7,8,9,11,16,27,30	GPS(6): 1,7,8,9,11,16,27,30
GLONASS(6): 9,10,11,19,20,21	GLONASS(6): 9,10,11,19,20,21
BDS(7): 1,2,3,7,8,10,13	BDS(7): 1,2,3,7,8,10,13
GALILEO(0):	GALILEO(0):
SBAS(0):	SBAS(0):
<b>Receiver Clock</b>	
GPS Week: 1948	
GPS Seconds: 370856	

### 5.1.2. ACTIVITY SUBMENU

Lists several important items to help you understand how the receiver is being used and its current operating condition. Items include the identities of currently tracked satellites, internal and external storage usage rate, how long the receiver has been operational, state of the internal battery, power source state, files being logged, and data streams being output. With this information, it is easy to tell exactly what functions the receiver is performing:


Activity	
<b>Satellites Track: 20Total</b>	<b>Activity Status</b>
GPS(6): 1,7,8,9,11,16,27,30	Current Time: 2017-05-11 07:02:49 (UTC)
GLONASS(6): 9,10,11,19,20,21	Operation Duration: 00:00:00 00:21:04
BDS(6): 2,3,7,8,10,13	Internal Storage: <input type="text" value="0.68%"/> 202MB/29728MB
GALILEO(0):	External Storage: <input type="text" value="0%"/> Disconnected
SBAS(0):	External Power: Connected
	Battery A: <input type="text" value="0%"/>
	Battery B: <input type="text" value="0%"/>

Data Log			
Recording Number	File Name	Activated	Log Status
1	recor41	No	Inactive
2	recor42	No	Inactive
3	recor43	No	Inactive
4	recor44	No	Inactive
5	recor45	No	Inactive
6	recor46	No	Inactive
7	recor47	No	Inactive
8	recor48	No	Inactive

Data Export		
Port Type	Output Data	
1	RTK Client	---
2	TCP/UDP_Client1/Netip	---
3	TCP/UDP_Client12/Netip	---
4	TCP/UDP_Client3/Netip	---
5	TCP/UDP_Client4/Netip	---
6	TCP/UDP_Client5/Netip	---
7	TCP/UDP_Client6/Netip	---
8	TCP Server/NetIP Caster	---
9	TCP Server/NetIP Caster	---
10	TCP Server/NetIP Caster	---
11	TCP Server/NetIP Caster	---
12	Serial Port	GP0GA_5c
13	Bluetooth	GP0GA_5c
14	Radio	---
15	GNSS	---

### 5.1.3. GOOGLE MAP SUBMENU

Tap this submenu to show the location of the receiver on Google map.



## 5.2. SATELLITES MENU

Use the Satellites menu to view satellite tracking details and enable/disable GPS, SBAS, GLONASS, BDS and Galileo constellations. These menus include tabular and graphical displays to provide all required information on satellite tracking status.



### 5.2.1. TRACKING TABLE SUBMENU


Provides the status of satellites tracked in general, such as the satellite ID, satellite type, attitude angle, azimuth angle, L1 SNR, L2 SNR, L5 SNR and enable/disable status of each one.

ID	Type	Elevation Angle	Azimuth Angle	L1 SNR	L2 SNR	L5 SNR	Enabled
1	GPS	60	190	43.024	36.926	0.000	Yes
7	GPS	62	291	50.767	42.422	0.000	Yes
9	GPS	61	111	50.687	43.187	0.000	Yes
9	GPS	14	234	39.879	30.855	0.000	Yes
11	GPS	64	202	50.450	42.431	0.000	Yes
16	GPS	21	92	36.483	30.539	0.000	Yes
27	GPS	39	14	45.022	33.664	0.000	Yes
30	GPS	26	315	43.215	32.081	0.000	Yes
9	GLONASS	27	132	43.719	45.671	0.000	Yes
10	GLONASS	32	9	48.961	44.604	0.000	Yes
11	GLONASS	22	329	39.639	41.404	0.000	Yes
19	GLONASS	12	31	33.631	27.796	0.000	Yes
20	GLONASS	64	4	41.431	48.119	0.000	Yes
21	GLONASS	50	236	45.855	46.211	0.000	Yes
2	BDS	26	235	37.007	40.947	41.625	Yes
3	BDS	163	260	42.463	43.531	45.378	Yes
4	BDS	26	121	32.847	38.953	0.000	Yes
7	BDS	81	92	36.431	45.692	47.690	Yes
8	BDS	22	223	27.564	45.706	47.531	Yes
10	BDS	69	325	38.828	44.253	45.898	Yes
13	BDS	44	221	37.359	40.187	42.245	Yes




### 5.2.2. TRACKING INFO. TABLE SUBMENU

The following figure is an example of satellite track diagram page. Users can determine the satellite types and the corresponding SNR of L-band carriers to be displayed in any combination.




### 5.2.3. TRACKING SKYPLLOT SUBMENU

The following figure is an example of Skyplot page.




### 5.2.4. SATELLITE ACTIVATION SUBMENU

Use this menu to enable or disable satellites.



### 5.3. RECEIVER CONFIGURATION MENU

Use this menu to configure settings such as the antenna type and height, elevation mask and PDOP setting, the reference station coordinates, receiver resetting and web interface language:



#### 5.3.1. DESCRIPTION

This submenu shows the receiver information and reference station information, including antenna related information, elevation mask angle, reference station work mode and position, etc.

Receiver Summary	
<b>Receiver Info:</b>	<b>Reference Station Info:</b>
Antenna Type: CHCM6	Reference Station Mode: Auto Rover
Antenna SN: 1021471	Reference Latitude: 0°0'0.00000000*(South)
Measure Way: Antenna Phase Center	Reference Longitude: 0°0'0.00000000*(West)
Antenna Height: 2.0000(Meter)	Reference Height: 0.0000
Elevation Mask: 20	
PDOP Mask: 6	

#### 5.3.2. ANTENNA CONFIGURATION SUBMENU

Use this screen to configure all the items relating to the GNSS antenna. You must enter the correct values for all antenna-related fields, as the choices you make significantly affect the accuracy for logged data and broadcast correction data:

 A screenshot of the 'Antenna Configuration' form. The form has a title 'Antenna Configuration' and contains several fields: 'Measure Way' (dropdown menu set to 'Antenna Phase Center'), 'Antenna manufacturer' (dropdown menu set to 'CHCNav'), 'Antenna Type' (dropdown menu set to 'CHCM6'), 'Antenna SN' (text input field with '1021471'), 'Antenna Height' (text input field with '2.0000' and '(Meter)' to its right), 'Elevation Mask' (text input field with '20'), and 'PDOP Mask' (text input field with '6'). At the bottom of the form is a 'Save' button with a floppy disk icon.

### 5.3.3. REFERENCE STATION SETTINGS SUBMENU

Use this screen to configure settings such as the station coordinates and the broadcast station identifiers. You must enter accurate information in these fields, as this data significantly affects the accuracy of logged data files and broadcast correction data:

**Reference Station Settings**

Reference Station Mode:

Base Station Name:

Base Station ID:

Reference Latitude: ° ′ ″  N  S


Reference Longitude: ° ′ ″  E  W

Reference Height:

Sample for Average:

Positioning Constraint:  Single Solution Coordinates  Fixed Solution Coordinates

Sampling Amount:  ✓ Start ✗ Stop

 Save


**Reference Station Settings**

Reference Station Mode:

Sample for Average:

Positioning Constraint:  Single Solution Coordinates  Fixed Solution Coordinates

Sampling Amount:  ✓ Start ✗ Stop

 Save

**Reference Station Settings**

Reference Station Mode:

Base Station Name:

Base Station ID:

Reference Latitude: ° ′ ″  N  S


Reference Longitude: ° ′ ″  E  W

Reference Height:

Sample for Average:

Positioning Constraint:  Single Solution Coordinates  Fixed Solution Coordinates

Sampling Amount:  ✓ Start ✗ Stop

 Save

**For Reference Station Mode:**

There are three modes available:

- a) **Auto Rover:** The receiver will serve as a rover after this mode is enabled, and then receive correction data through the working mode set last time.
- b) **Auto Base:** The receiver will serve as a base after this mode is enabled, and then broadcast correction data based on coordinate inputted by user, or obtained through autonomous positioning automatically.
- c) **Manual Base:** The receiver will serve neither as a base or a rover after this mode is enabled. Users need to configure the receiver manually.

**For Reference Latitude and Reference Longitude:**

There are mainly three methods to enter the reference coordinates and shown as follows:

- a) **Acquire Current Position:** Click this button to acquire current position obtained through autonomous positioning automatically.
- b) **Manual Input:** Manually input the coordinate of a control point.
- c) **From CORS:** After the receiver logging in CORS, the software can record the coordinate of current position based on fix solution.

**For Sample for Average:**

Users can determine the positioning limit and sampling amount. The positioning limit falls into two types:

- a) **Single Solution Coordinates:** Collect the coordinates of receiver obtained through autonomous positioning.
- b) **Fixed Solution Coordinates:** Only collect coordinates of receiver with a fixed solution.

After the configuration of positioning limit and sampling amount, click



to carry out sampling and averaging → the progress bar will show the progress → the result will be served as the coordinate of current position.

If users need to save the changes, please tap  button.

### 5.3.4. RECEIVER RESET SUBMENU

Use this screen to completely or partially reset the receiver:

**Receiver Reset**

- Reboot Receiver:  Confirm
- Clear Satellite Data:  Confirm
- Reset To Defaults:  Confirm
- Turn Off Receiver:  Confirm

### 5.3.5. LANGUAGES SUBMENU

Use this screen to select the web interface language:

**Language**

English  Confirm

中文

English

Русский

Türkçe

Español

### 5.3.6. USER MANAGEMENT SUBMENU

**User Management**

Add  Save  Delete  Modify Anti-theft password

ID	User Name	Password
1	admin	*****
2	admin1	*****
3	admin2	*****

### 5.3.7. USB FUNCTION SWITCH SUBMENU

Use this menu to switch between USB personal area network and Multimedia storage.

**USB Function Switch**

USB Function Switch:  USB personal area network  Multimedia storage

### 5.3.8. HCPPP SETTINGS SUBMENU

Use this menu to select HCPPP Range.


**HCPPP Settings**

HCPPP Range: 5min

Save


### 5.3.9. 1PPS SUBMENU

Use this button to turn on or turn off 1PPS.



## 5.4. DATA RECORDING MENU

Use the Data Logging menu to set up the receiver to log static GNSS data and to view the logging settings. You can configure settings such as observable rate, recording rate, continuous logging limit, and whether to auto delete old files if memory is low. This menu also provides the controls for the FTP push feature:



### 5.4.1. LOG SETTINGS SUBMENU

Here shows the data logging status, including internal and external storage usage and data logging status of each session. Also, users can configure the data logging settings for each session, including recording name, store location, storage limit, store formats, start time, etc.

Store Info			
Position	Total Storage	Storage Available	
1 Internal Storage	2972MB	2952MB	
2 External Storage	0MB	0MB	

Attention: Total assigned storage size of 8 threads should be less than 27GB. It will stop recording when the storage is full.

Record Info							Clear All
Recording Name	File Name	Activated	Log Status	Setting Parameter	Switch	Clear Data	
1	record1	No	Not Recording	Modify/Detail	ON/OFF	Clear	
2	record2	No	Not Recording	Modify/Detail	ON/OFF	Clear	
3	record3	No	Not Recording	Modify/Detail	ON/OFF	Clear	
4	record4	No	Not Recording	Modify/Detail	ON/OFF	Clear	
5	record5	No	Not Recording	Modify/Detail	ON/OFF	Clear	
6	record6	No	Not Recording	Modify/Detail	ON/OFF	Clear	
7	record7	No	Not Recording	Modify/Detail	ON/OFF	Clear	
8	record8	No	Not Recording	Modify/Detail	ON/OFF	Clear	

To edit the settings of each session, click the **Modify** button to the right of the required session, and then the *Recording Edit* screen appears:

The 'Recording Edit' window contains the following fields and controls:

- Auto Record:  Yes  No
- Sample Interval: 5s (dropdown)
- Elevation Mask: 20 (text input) (°)
- Duration Time: 1440 (text input) (Minute)
- Site Name: 1021471 (text input)
- Antenna Height: 0.0000 (text input)
- Measure Way: Slant Height (dropdown)
- Storage Format: HCN (dropdown)
- RINEX Version: OFF (dropdown)
- Advanced (button)
- Save (button) Back (button)



Click advanced to see more settings.

The 'Advanced' window contains the following fields and controls:

- Start Date:  Yes  No
- Apply Time:  Yes  No
- Integral Point Store:  Yes  No
- Circulating Memory:  Yes  No  
the data overwritten first file after storage space is full
- Repeat Observations:  Yes  No  
Turn on to record a single observation. Turn off to record repeated observations.
- Store Location: Internal Storage (dropdown)
- Assigned Storage: 10000 (text input) (MB)
- Observer: CHC (text input)
- Observe Agency: CHC (text input)
- FTP Push:  Close  
 1:ftp server 1  
 2:ftp server 2  
 3:ftp server 3

In this screen, you can configure all the data logging parameters, and determine whether the recording files will be affected by the FTP Push. The parameters are mainly as follows:

- **File Name:** The name of this logging session.
- **Sample Interval:** Select the observable rate from the dropdown list.
- **Store Location:** Determine whether to store at internal storage or external storage.
- **Enable Start Time:** Set the start time of data logging in UTC. Select **Or not** option below to determine whether to start data logging from the start time defined, or immediately after this session is switched on.
- **Duration Time:** Set the duration of data logging.
- **Assigned Storage:** Set the storage space of this session.
- **Circulating Memory:** Select **Yes** or **No** option to determine whether to auto delete old files if the storage space is full.
- **Data Format:** Set the data format of the logged data.
- **FTP Push:** Decide whether to push the stored files to the FTP server of your choice.

Tap  **Save** button to save the settings and back to the *Log Settings* screen. Also, users can click  **Back** to abandon the changed settings and back to *Log Settings* screen.

*Note – To modify data logging parameters, make sure the data logging session is switched off.*

To switch on or off **ANY** data logging session, tap the **ON** or **OFF** button to the right of the required session.

To delete the recorded files of **ANY** data logging session, tap the **Clear** button to the right of the required session.

To delete the recorded files of **ALL** data logging sessions, tap the **Clear ALL Accounts** button.

#### 5.4.2. FTP PUSH SETTINGS SUBMENU

Use this screen to configure the receiver to push stored files to the FTP server of your choice. Only files that are configured to use FTP push are transmitted.

FTP Push Settings

Server ID	Server IP	Remote Directory	Server Description	Modify
1	192.168.3.72	/repo/first	ftp server 1	<a href="#">Modify</a>
2	192.168.3.72	/repo/second	ftp server 2	<a href="#">Modify</a>
3	192.168.3.72	/repo/third	ftp server 3	<a href="#">Modify</a>

Tap **Modify** button to the right of the required FTP server and the *FTP Push Settings* screen appears:

FTP Push Settings

Server IP:



Port:

Remote Directory:

Server Description:

User Name:

Password:

 **Save**  **Back**



### 5.4.3. FTP PUSH LOG SUBMENU

Shows the related information about the recorded files that were pushed. And users can tap **Clear Ftp Send Log** button in the upper right corner to clear the log of FTP Push operations.



### 5.4.4. DATA DOWNLOAD SUBMENU


In this submenu, users can download the data files that were recorded in the internal storage through the internal FTP site.

1. Click this submenu, and then the log on dialogue box will prompt you to enter a user name and password:

The default logon account for the internal FTP site is:

- User name: ftp
- Password: ftp

2. Click the directory named as “repo” to view and download the files currently stored on the receiver:




3. To find the file need to be downloaded, click the name of data logging session → the date of file that be recorded → the format of the file → the name of the target file.

## Index of /repo/record\_1/20150518/rinex/

Name	Size	Date Modified
[parent directory]		
1000514138D.15C	0 B	5/18/15 3:04:00 AM
1000514138D.15G	0 B	5/18/15 3:04:00 AM
1000514138D.15N	0 B	5/18/15 3:04:00 AM
1000514138D.15O	8.0 kB	5/18/15 3:04:00 AM
1000514138F.15C	0 B	5/18/15 5:56:00 AM
1000514138F.15G	0 B	5/18/15 5:56:00 AM
1000514138F.15N	0 B	5/18/15 5:56:00 AM
1000514138F.15O	240 kB	5/18/15 5:59:00 AM
1000514138I.15C	0 B	5/18/15 8:15:00 AM
1000514138I.15G	0 B	5/18/15 8:15:00 AM
1000514138I.15N	0 B	5/18/15 8:15:00 AM
1000514138I.15O	64.0 kB	5/18/15 8:16:00 AM

- To download a file, left-click the name of the target file → download the file according to the prompts.

### 5.5. IO SETTINGS MENU



Use the IO Settings menu to set up all receiver outputs and inputs. The receiver can output CMR, RTCM, Raw data, Ephemeris data, GPGGA, GPGSV, on TCP/IP, UDP, serial port, or Bluetooth ports.

#### 5.5.1. IO SETTINGS SUBMENU


The following figure shows an example of the screen that appears when you select this submenu.

I/O Settings					
	Type	Description	Output	Connection Status	Modify
1	RTX Client	211.144.118.5:2102	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
2	TCP/UDP_Client1/RTXIP Serv	192.168.3.18:9900	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
3	TCP/UDP_Client2/RTXIP Serv	192.168.3.18:9901	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
4	TCP/UDP_Client3/RTXIP Serv	192.168.3.18:9902	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
5	TCP/UDP_Client4/RTXIP Serv	192.168.3.18:9903	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
6	TCP/UDP_Client5/RTXIP Serv	192.168.3.18:9904	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
7	TCP/UDP_Client6/RTXIP Serv	192.168.3.18:9905	---	Disconnected	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
8	TCP Server/RTXIP Cluster1	9901	---	Closed	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
9	TCP Server/RTXIP Cluster2	9902	---	Closed	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
10	TCP Server/RTXIP Cluster3	9903	---	Closed	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
11	TCP Server/RTXIP Cluster4	9904	---	Closed	<a href="#">Connect</a> <a href="#">Disconnect</a> <a href="#">Data</a>
12	Serial Port	9600	---	---	<a href="#">Settings</a>
13	Bluetooth	GNSS-1013103	GPGGA, GPRMC	---	<a href="#">Settings</a>
14	Radio	462.050MHz	---	---	<a href="#">Settings</a>
15	GSM	Bearer	---	Offline	<a href="#">Settings/Connect</a>


In this submenu, users can configure 6 types of input and output settings.

## 1. RTK Client

After configuring the settings of RTK client, users can log on CORS or APIS. Tap the **Connect** button to the right → the *IO Settings* screen will appear → choose one of the connection protocols among the NTRIP, APIS\_BASE and

APIS\_ROVER → configure the related parameters → click  to log on CORS or APIS.

## ➤ Connection Protocol: NTRIP




The screenshot shows the 'RTK Client' configuration window with the following settings:

- Connection Protocol: NTRIP
- Server IP: 108.171.124.25
- Port: 2103
- Mount Point: CHC-&-GEO (with a green checkmark and 'Get' text)
- User Name: user
- Password: 1234

At the bottom, there are 'Confirm' and 'Back' buttons.

## ➤ Connection Protocol: APIS\_BASE




The screenshot shows the 'RTK Client' configuration window with the following settings:

- Connection Protocol: APIS\_BASE
- Server IP: 111.111.111.1
- Port: 9901
- Differential Data: OFF

At the bottom, there are 'Confirm' and 'Back' buttons.

## ➤ Connection Protocol: APIS\_ROVER





The screenshot shows the 'RTK Client' configuration window with the following settings:

- Connection Protocol: APIS\_ROVER
- Server IP: 210.14.66.58
- Port: 9902
- Base ID: (empty dropdown)


At the bottom, there are 'Confirm' and 'Back' buttons.

## 2. TCP/UDP Client


Tap the **Connect** button to the right of required TCP/UDP Client → the *IO Settings* screen will appear → select the connection protocol between TCP and UDP → enter the IP and Port of the target server → configure messages that you want to output to the target server → click  to save and complete the connection.




## 3. TCP Server/NTRIP Caster

Tap the **Connect** button to the right of required TCP Server/NTRIP Caster → the **IO Settings** screen will appear → select one of the connection protocols between NTRIP and TCP → configure the other related parameters → click  to save the settings and open the server.

## ➤ Connection Protocol: NTRIP



## ➤ Connection Protocol: TCP




## 4. Serial Port

Tap the **Settings** button to the right of Serial Port → the *Serial Port Setup* screen will appear → select Baud Rate used to transmit data → configure the messages that you want to output through the serial port → click





to save the settings and start to transmit.



## 5. Bluetooth


Tap the **Settings** button to the right of Bluetooth → the *Bluetooth Set* screen will appear → configure the messages that you want to transmit through

Bluetooth → click  to save the settings and start to transmit.




## 5.6. NETWORK SETTING MENU

Use this menu to view network information, configure the receiver's mobile network, set email alert for specific situation, configure HTTP or HTTPS port, and the user name and password of internal FTP site:



### 5.6.1. DESCRIPTION SUBMENU

Use this submenu to check the information of network setting.



### 5.6.2. MOBILE NETWORK SETTING SUBMENU

Use this submenu to configure GPRS model, network module and modify dialing status.

**Mobile Network Setting**

GPRS Model Status: ON  ON  OFF

Auto Start:  Yes  No

Network Mode:  2G Only  3G Only  2G/3G Auto

Dialing Status: Offline  Dial  Break

Auto Connect:  Yes  No

GSM:

APN:

Dialing String:

User Name:

Password:

### 5.6.3. EMAIL ALARM SUBMENU

Use this submenu to choose which situation of receiver will be alerted and input the email address.

**Email Alert Settings**

**TO**

Email Address 1:

Email Address 2:

Email Address 3:

**From**

Account:

Password:

Server Address:

**Email Alert**

- Receiver is powered on
- External power is off
- Battery level is low
- Ftp push is failed
- Receiver(license) will be expired in 7 days.

### 5.6.4. HTTP SUBMENU


Use this submenu to configure HTTP port.

**HTTP**

HTTP Port:

### 5.6.5. HTTPS SUBMENU


Use this submenu to configure HTTPS port.



**HTTPS**


Enable HTTPS:  Yes  No

HTTPS Port:

 Save

#### 5.6.6. FTP SERVICE SUBMENU


Use this submenu to configure the user name and password of internal FTP site.



**FTP Settings**


User Name:

Password:




 Save

### 5.7. MODULE SETTING MENU

Use this menu to check module information, configure Wi-Fi, Bluetooth, radio related settings:



**Module Setting**

-  Description
-  WiFi
-  Bluetooth Settings

#### 5.7.1. DESCRIPTION SUBMENU

Use this submenu to check the information of Wi-Fi module, Bluetooth module and radio module.



Module Abstract	
<b>Wi-Fi Information:</b> Power Status: ON Wifi Mode: Access Point MAC: de:ad:be:02:14:71	<b>Radio Information:</b> Radio Type: Radio Power: OTA Baud Rate: Radio Frequency: 0.0000MHz Radio Protocol: Radio Frequency Channel: Frequency Range: undefinedMHz--undefinedMHz
<b>Access Point Details</b> SSID: GNSS-1021471 Encryption Type: WAP Password: 12345678	

### 5.7.2. WI-FI SUBMENU

Use this submenu to turn on/off Wi-Fi function and modify password.

**WiFi**

Power Status: ON  ON  OFF

Auto Start:  Yes  No  
 Internet:  Yes  No

---

Wifi Mode:

SSID:

Encryption Type:

Password:

### 5.7.3. BLUETOOTH SETTINGS SUBMENU

Use this submenu to turn on/off Bluetooth function and modify PIN number.

**Bluetooth Settings**

Local Name: GNSS-1021471  
 MAC Address: 20:C3:8F:A2:08:40

Visible:  Yes  No

PIN:

### 5.7.4. BUZZER SETTING SUBMENU


Use this submenu to turn on/off static voice.

**Buzzer Setting**

Static Voice  On  Off


## 5.8. FIRMWARE MENU

Use this menu to check the current firmware information, download the system log, update the receiver firmware, download or update the configuration file and register the receiver, and more:




### 5.8.1. FIRMWARE INFO SUBMENU

Use this submenu to check the current firmware information. The following figure shows an example of the firmware information.




### 5.8.2. HARDWARE VERSION

Use this submenu to check the hardware information, including main board version and core board version:




### 5.8.3. CONFIG FILE

Use this submenu to update Configuration File.




### 5.8.4. SYSTEM LOG DOWNLOAD SUBMENU

Use this submenu to download the system log of the receiver.




### 5.8.5. USER LOG



### 5.8.6. FIRMWARE UPDATE SUBMENU

Use this submenu to load new firmware to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.



## Notes

- It may take about 3 or 4 minutes to complete the firmware upgrading. Do not touch the power button or unplug the power until the upgrading process is finished, or damage will be caused to the receiver.
- The receiver will restart after the firmware upgrading is done, so users need to reconnect the receiver with your computer via Wi-Fi, and then log-in the receiver through a web browser to continue the configuration.

## 5.8.7. GNSS BOARD UPGRADE

Use this submenu to upgrade GNSS Board.

## 5.8.8. RADIO UPGRADE

Use this submenu to browse upgrade file and upgrade radio.

## 5.8.9. UPGRADE ONLINE

Use this submenu to input Server Address and upgrade online.

File Name	Version	Description	Size	Upgrade
Get File List				

## 5.8.10. GNSS REGISTRATION SUBMENU

Use this submenu to register the receiver. Paste or enter the registration code to the *Registration Code* field → tap **Registration** button to complete the registration.

## 5.9. CLOUD SERVICE SETTING MENU

### 5.9.1. CLOUD SERVICE SETTING SUBMENU

#### Cloud Service Setting

 Cloud Service Setting

Use this submenu to turn on or turn off Cloud Service, Auto Start, Remote Control and configure other settings.

#### Cloud Service Setting

Cloud Service States  ON  OFF

Auto Start

Remote Control  On  Off

Anti-theft

It cannot modify server IP in anti-theft mode and the function will auto on and upload location info!

Next

Upload position  On  Off

Time Interval

Position Interval

Address

Port

## A. COMMUNICATION PORTS DEFINITION

### A.I. CHC M6 RECEIVER IO PORT (7-PIN LEMO PORT) DEFINITION



PIN	FUNCTION
1	Ground ( - )
2	Ground ( - )
3	RS232-TX (Output)
4	PPS
5	Not Used
6	VIN
7	RS232-RX (Input)

CHC - Shanghai Huace Navigation Technology Ltd.  
Building C, NO. 599 Gaojing Road,  
Qingpu District, 201702 Shanghai, China  
Tel: +86 21 542 60 273  
Fax: +86 21 649 50 963  
Email: [sales@chcnav.com](mailto:sales@chcnav.com) | [support@chcnav.com](mailto:support@chcnav.com)  
Website: [www.chcnav.com](http://www.chcnav.com)